


How to shut down CM5 S8800 and CMM Servers

Click on **Shutdown Server** option, make sure **Delayed Shutdown** is selected and **Restart server after shutdown** is not ticked then click **Shutdown**



AVAYA Communication Manager (CM)
System Management Interface (SMI)

Help Log Off Installation Administration Upgrade Duplicate Server: [2] IDEAL_8730_B
Administration / Server (Maintenance) This Server: [1] IDEAL_8730_A

Shutdown Server

The Shutdown Server Web page provides options to shutdown the server.

Warning: Shutting down this server will also stop the web server you are currently communicating with, so you will be unable to access these web pages until the system starts again. Requesting 'Immediate Shutdown' of this server ignores the state of health of any duplicate server and affects how the duplicate server takes over from the main server.

This Server is currently: active

Delayed Shutdown Wait for all processes to terminate normally

Immediate Shutdown - Shutdown now, do **NOT** wait for processes to terminate normally

Restart server after shutdown

Shutdown even if this is the active server (or Shutdown even if this is the standby server and it is not busied out)

Shutdown **Help**

© 2001-2009 Avaya Inc. All Rights Reserved.