

Shutdown Avaya System Platform

To Shutdown an Avaya System Platform browse to the System Platform Console Domain IP address and login with your username and password (customer/p0rtugal):



Then go to "Server Management", "Server Reboot / Shutdown" and select "Shutdown Server"

